

# Fume Eliminator 840/841

Fume Eliminator 840/841 is a small, lightweight, portable extraction unit designed to be carried to the working area. Connected to a welding torch or to an extraction nozzle, the FE 840/841 unit extracts the fume directly at source. FE 840 has a manual start/stop function. FE841 has an automatic start/stop function which starts the unit as soon as the welding begins. It also includes an indicator for filter exchange.



- Portable, easy to carry
- Low service costs

	Voltage, V / electrical plug	Power, W	Airflow with 2.5 m hose, m <sup>3</sup> /h	Filtration efficiency	Max. vacuum, kPa %	Noise level, dB(A)	Length, mm	Width, mm	Height, mm	Weight, kg	Part no.
FE 840 Manual start/stop	230/EUR	1000	150	99.7	22	73	830	230	410	16	70840000
FE 840 Manual start/stop	120/UK	1000	150	99.7	22	73	830	230	410	16	70840100
FE 840 Manual start/stop	240/UK	1000	150	99.7	22	73	830	230	410	16	70840442
FE841 Auto start/stop	230/EUR	1000	150	99.7	22	73	830	230	410	16	70841000
FE841 Auto start/stop	120/UK	1000	150	99.7	22	73	830	230	410	16	70841100
FE 841 Auto start/stop	240/UK	1000	150	99.7	22	73	830	230	410	16	70841010

Accessories	Part no.
Nozzle TM 80, length 500 mm, Ø80 mm	70851000
Nozzle TM 200, length 570 mm, slot width 200 mm, slot height 30 mm	70854000
Nozzle PM 300, slot width 300 mm, slot height 5 mm	70853000
Hose, Ø45 mm, 5 metres	70400026
Hose, Ø45 mm, 15 metres	70400028